


THE WALL-MIC's INSTRUCTIONS



The WALL-MIC can be mounted to a wall or a beam and many units can be daisy chain together. The units are only activated when the button is held in. The button will buzz the CRANE PHONE if it is off.

Great for hoist operators or when ever using in multiple stationary locations

